



Linear 21st Sentry CP-90 Program Sheet

- Enter Program** 9 + 98765 (System must be disarmed to Level 0 first)
- Exit Program** * for 4 seconds
- Show Version** {bmct liquest.shg} + 90
- Compatible Wireless Sensors**
- | | |
|-------------------------------|--------------------------------------|
| 40S40A/70S60 Motion Detector | ST-23 Money Trap |
| ESL 371 Smoke Detector | T-90 Door/Window |
| LMT-1 Portable Panic | TGB-90 Glassbreak Detector |
| ST Series Door/Window Sensors | TSD-90A Smoke Detector |
| ST-1 Portable Panic | TX-91, TX-92, TX-94 Hand Held Panics |
- Zone Config**
- Zones 1 to 3 = Hardwired Zones
 Zones 4 to 64 = Wireless Zones
 Zones 65 to 72 = Hardwired Keypads
- Default Panel** Hold MASTER RESET button in panel for 10 seconds while powering up
- Programming Hints**
1. After entering programming you start out at Function 0
 2. Enter location to program (example: Location 50) then press {bmct liquest.shg}
 3. Choose Selector (Example: 2 for Communication Fmt 1) then {bmct liquest.shg}
 4. Enter new Value (Example: 11 for SIA format) then press {bmct libypass.shg} to save
 5. You should hear a "Happy Tone" indicating okay, a "NA NA" tone means bad data
 6. This takes you back to Location 50, enter new location or press {bmct liquest.shg} to re-enter Location 50 to program other locations, * exits back to location 0

(FUNCTION is the Location of a group of)
 (SELECTOR is a program location within a FUNCTION)
 (VALUE is the data stored within a SELECTOR)

Keypad Commands

-  << Stores (Saves) Data
-  << Cycles through Fields
-  << Counts Up through Options
-  << Reset Data to Default Value
-  << Counts Down through Options
-  << Clears Display/ Exits Location

LCD Display

FUNCT=070 SEL=034 VAL=001
 FORCE ARM REPORT CODE

LED Display


 At Function Prompt


 At Selector Prompt


 At Value Prompt

FUNCTION	SELECTOR	Description	Action or Value
0	0	Display installed Sensor	1. Press 0 +  +  2. Press  (keypad will scroll all zones) 3. Press  to stop scrolling 4. Press * to exit
1	0	Auto-install RF Sensors	1. Press 0 +  +  2. Display shows currently installed sensors 3. Press  (keypad will sound tone) 4. Activate sensor, it installs on next available zone (Caution: a sensor can be learned into multiple zones) 5. Press  to exit
2	4-64	Manually install RF Sensor	1. Press 2 +  + Zone (4 to 64) +  2. Press  then activate Sensor (keypad will beep when learned, press * to exit) (Learn TK-90 Wireless keypad as a zone, no zone type)

Linear 21st Sentry CP-90 Program Sheet

FUNCTION	SELECTOR			
3	4-64	Manually remove RF Sensor		1. Press 3 + <input style="width: 30px;" type="text" value="???"/> + Zone (4 to 64) + <input style="width: 30px;" type="text" value="???"/> 2. Press <input type="button" value="←"/> to delete sensor (keypad will beep when deleted, press * to exit)
4	1-64	Sensor Zone Type		1. Press 4 + <input style="width: 30px;" type="text" value="???"/> + Zone (4 to 64) + <input style="width: 30px;" type="text" value="???"/> 2. Enter Zone Type then press <input type="button" value="←"/> (keypad will beep, press * to exit)
	0	Exterior		Arm Levels 3, 4, 5 & 6 - Chimes in Level 2
	1	Restricted Interior		Arm Levels 4, 5 & 6
	2	Interior		Arm Levels 4, 5 & 6
	3	Fire		24-Hour Fire Zone
	4	Emergency		24-Hour Emergency Zone
	5	Police/Hold-Up		24-Hour Police/Holdup Zone
	6	Arm/Disarm Toggle		Sensor is Pushbutton that arms to Level 4 or 1
	7	Remote Panic		Hold 3-Seconds Triggers 24-Hour Duress
	8	Remote Panic/Police		Hold 3-Seconds Triggers 24-Hour Police
	9	Guard Zone		(Types 6, 7, and 8 can be used for keyfob, see Function 17 for button assignments) Arm Levels 1, 2, 3, 4, 5 & 6 reports as Burg in Level 4
	10	Environmental Type A		24-Hr Zn, Triggers Audible, Violation & No Reports
	11	Environmental Type B		24-Hr Zn, Triggers Audible Only, Violation, No Reports
	12	Environmental Type C		24-Hr Zn, Triggers Audible Only, No Violation, No Reports
	13	Chime Only		Active Levels 1, 2 & 3, Chime Only, No Violation & Reports
	14	Automation #1		Triggers Automation #1 Output on Control Output
	15	Automation #2		Triggers Automation #2 Output on Control Output
	16	Access Only		Triggers Access Output on Control Output
	17	TX Remote Disable		"Dead" Zone to Disable Buttons on TX Remotes
5	1-64	Sensor Entrance Delay	<input style="width: 30px;" type="text" value="0"/>	0 = Instant 1 = Delay One (See Function 120-1) 2 = Delay Two (See Function 120-2) 3 = Interior Follower
6	4-64	Sensor Type	<input style="width: 30px;" type="text" value="0"/>	0 = Normal Open/Close Sensor 1 = PIR
7	4-64	RF Sensor Supervision	<input style="width: 30px;" type="text" value="0"/>	0 = Supervised 1 = Unsupervised
8	1-64	Sensor Local Alarm	<input style="width: 30px;" type="text" value="0"/>	0 = Audible 1 = Silent
9	1-64	Sensor Bypassing	<input style="width: 30px;" type="text" value="0"/>	0 = Can be Bypassed (All others) 1 = Cannot be Bypassed (Fire Zones)
10	1-64	Sensor Audio Reporting	<input style="width: 30px;" type="text" value="2"/>	0 = No Sensor Audio 1 = Listen Only Audio 2 = Two-Way Audio
11	0	Hardwire Zone 1, 2 & 3 Auto Setup		1. Press 11 + <input style="width: 30px;" type="text" value="???"/> + <input style="width: 30px;" type="text" value="???"/> 2. Press <input type="button" value="←"/> to install Zones 1 2 and 3 (All Zones MUST be closed to install properly) 3. Press * to exit 4. Remove unused hardwire zones in step 15
12	1-3	Hardwire Loop Response Time	<input style="width: 30px;" type="text" value="4"/>	(1 to 100 x100 ms)
13	1-3	Hardwire Loop Supervision	<input style="width: 30px;" type="text" value="0"/>	0 = EOL Supervised (2.2k) 1 = No EOL
14	1-3	Hardwire Loop Trouble Type	<input style="width: 30px;" type="text" value="0"/>	0 = No Trouble 1 = Trouble on Open 2 = Trouble on Short 3 = Trouble on Open or Short
15	1-3	Hardwire Loop Disable	<input style="width: 30px;" type="text" value="0"/>	0 = Loop Disabled 1 = Loop Enabled

Linear 21st Sentry CP-90 Program Sheet

FUNCTION	SELECTOR		
16	1-64	KD-90 LCD Zone Descriptions	<p>Enter location from regular programming by pressing 16 + [???</p> <p>1. Enter Zone to program (01 to 64) then [???</p> <p>2. Enter 1 to 3 digit number from chart to create first word then []</p> <p>3. Enter next word + []</p> <p>4. Continue until finished (up to 24 characters)</p> <p>5. Press * to exit</p> <p>(see last page of program sheet for all descriptors)</p>
17	3-17	Zone Select for TX-91, TX-92 Remotes	<p>1. First learn Remote by Function 2</p> <p>2. Press 17 + [???] + 1st button Zone Type + [???] + [] press Keyfob button</p> <p>3. Press 17 + [???] + 2nd button Zone Type + [???] + [] press Keyfob button</p> <p>4. Continue until all buttons are learned (top button can't be learned and is always a panic)</p> <p>5. Press * to exit</p>
20	0	Display Keypads in Memory	<p>1. Press 20 + [???] + [???] + []</p> <p>2. Display shows number of Keypads installed, press []</p> <p>3. Display scrolls what zone keypad occupies and keypad type</p> <p>3. Press * to exit</p>
21	0	Auto-Install Keypads	<p>1. Press 21 + [???] + [???] + []</p> <p>2. Keypads will install automatically to Zones 65 to 72</p> <p>3. Press * to exit</p>
23	65-72	Manually Remove Keypad (1st keypad is Zone 65, 2nd is 66 etc)	<p>1. Press 23 + [???] + (65 to 72) + [???] + []</p> <p>2. Press * to exit</p>
24	65-72	Keypad Panic Keys Enable (1st keypad is Zone 65, 2nd is 66 etc)	<p>1. Press 24 + [???] + (65 to 72) + [???] + 0 to 7 + []</p> <p>2. Press * to exit</p> <p style="margin-left: 40px;">0 = Disable All Three Emergency Keys 1 = Police Key Active Only 2 = Emergency Key Active Only 3 = Emergency & Police Keys Active 4 = Fire Key Active Only 5 = Fire & Police Keys Active 6 = Fire & Emergency Keys Active 7 = Enable All Panic Keys</p>
Keypad Options (1st keypad is Zone 65, 2nd is 66 etc to 72)			
25	65-72	Standby Display Intensity	[0] 0 = Off 1 = Low 2 = Medium 3 = High
26	65-72	Standby Downlight Intensity	[0] 0 = Off 1 = Low 2 = Medium 3 = High
27	65-72	Active Display Intensity	[2] 0 = Off 1 = Low 2 = Medium 3 = High
28	65-72	Active Downlight Intensity	[2] 0 = Off 1 = Low 2 = Medium 3 = High
29	65-72	Keypad Lights on Entry Delay	[1] 0 = Lights Off 1 = Lights On
30	65-72	Keypad Lights on Exit Delay	[1] 0 = Lights Off 1 = Lights On
31	65-72	Keypad Beep Loudness	[2] 0 = Off 1 = Low 2 = Medium 3 = High
32	65-72	Keypad Annunciate Loudness	[2] 0 = Off 1 = Low 2 = Medium 3 = High
33	65-72	Keypad Alarm Loudness	[2] 0 = Off 1 = Low 2 = Medium 3 = High
34	65-72	Keypad Panic Audio Response (2-way)	[0] 0 = No Audio 1 = Listen-In 2 = Two Way
35	65-72	KD-90 Accessory LCD Captions	Enter names for keypad locations

Linear 21st Sentry CP-90 Program Sheet

Communicator Settings

50	1	Communicator On/Off	1	0 = Local System Only 1 = Communicator Enabled
	2	Communications Format #1	11	0 = 10PPS 3x1 Ademco 1400Hz
	3	Communications Format #2	11	1 = 10PPS 3x1 Extended 1400Hz
		(Changing formats here defaults values in Function 72)		2 = 10PPS 4x1 1400Hz
		Contact ID not available in versions before 2.10, always use SIA		3 = 10PPS 4x2 Silent Knight 1400Hz
				4 = 20 PPS 3x1 Sescoa 2300Hz
				5 = 20 PPS 3x1 Extended 2300Hz
				6 = 20PPS 4x1 2300Hz
				7 = 20PPS 4x2 2300Hz
				8 = 40PPS 3x1 2300Hz
				9 = 40PPS 3x1 Extended 2300Hz
				10 = BFSK 3x2
				11 = SIA
				12 = Sescoa Superspeed
				13 = Ademco Contact ID
	4	Dialing Format	0	0 = DTMF 1 = Pulse Dialing
	5	Opening Reports by Exception	0	0 = Normal 1 = Opening when Disarm after Alarm
	6	Closing Reports by Exception	0	0 = Normal Closing Reports 1 = Closings when Disarm after an Alarm
	7	Tamper Report Routing	0	0 = Reports on Supervisory Routing 1 = Reports on Alarm Routing
	8	Dialing Start Delay	0	0 to 250 Seconds
	9	Dialing Attempts	8	0 to 250 Attempts
	10	Dialing Attempts before Sleep Cycle	2	0 to 250 Attempts
	11	Number of Sleep Cycles Allowed	2	0 to 250 Cycles
	12	Sleep Cycle Time	10	1-250 Minutes before next dial
	13	Anti-Jam Time	40	1 to 250 Sec
	14	Automatic Test Report Delay	0	0 to 250 Hrs
	15	Swinger Eliminator Count	0	0 = All Violations Reported (Disabled) 1 -10 = # of Violations Sensor/Loop
	16	Remote Programming Lockout	1	0 = No Remote Programming 1 = Remote Programming Allowed
	17	Invalid Access Timeout	20	20 to 50 sec
	18	Automatic Test Report Interval	1	0 = Test Reports every 12 Hours 1-7 = Test Reports every 1-7 Days
	19	Inhibit Superspeed End of TX	0	0 = ETX at End of Report 1 = No ETX Sent at End of Report
	20	Listen-Only Audio After duress	0	0 = No Audio After Duress 1 = Listen-Only Audio After Duress
51	1	Remote Program Access Code	9 8 7 6 5 4	(000000 to 999999)
		1. Press 51 then	? ? ?	
		2. Press 1 then	? ? ?	to select 1st digit
		3. Press 9 then	/ / /	
		4. Press 8 then	/ / /	
		5. Press 7 then	/ / /	
		6. Press 6 then	/ / /	
		7. Press 5 then	/ / /	
		8. Press 4 then	/ / / + ? ? ?	

Linear 21st Sentry CP-90 Program Sheet

Report Codes for 4/2 Format only (this is 1st digit)

70	1	Fire Sensor/Loop	1	0 to 15 (0 = Disabled)
	2	Exterior Intrusion	3	0 to 15 (0 = Disabled)
	3	Interior Intrusion	5	0 to 15 (0 = Disabled)
	4	Police/Holdup	2	0 to 15 (0 = Disabled)
	5	Emergency	4	0 to 15 (0 = Disabled)
	6	Environmental	0	0 to 15 (0 = Disabled)
	7	Restore	14	0 to 15 (0 = Disabled)
	8	Sensor Tamper	0	0 to 15 (0 = Disabled)
	9	Bypassed Sensor	0	0 to 15 (0 = Disabled)
	10	Keypad Fire	1	0 to 15 (0 = Disabled)
	11	Keypad Police/Hold-Up	2	0 to 15 (0 = Disabled)
	12	Keypad Emergency	4	0 to 15 (0 = Disabled)
	13	Duress	0	0 to 15 (0 = Disabled)
	14	Opening	11	0 to 15 (0 = Disabled)
	15	Closing	12	0 to 15 (0 = Disabled)
	16	Cancel	13	0 to 15 (0 = Disabled)
	17	Communicator Auto Test	0	0 to 15 (0 = Disabled)
	18	Communicator Man. Test	0	0 to 15 (0 = Disabled)
	19	Control Panel Tamper	0	0 to 15 (0 = Disabled)
	20	Keypad Tamper	0	0 to 15 (0 = Disabled)
	21	Supervisory Trouble	15	0 to 15 (0 = Disabled)
	22	Control Panel Low Battery	0	0 to 15 (0 = Disabled)
	23	Control Panel Battery Restore	0	0 to 15 (0 = Disabled)
	24	AC Failure	0	0 to 15 (0 = Disabled)
	25	AC Restore	0	0 to 15 (0 = Disabled)
	26	Memory Error	0	0 to 15 (0 = Disabled)
	27	Auxiliary Fuse Blown	0	0 to 15 (0 = Disabled)
	28	Fire Power Fuse Blown	0	0 to 15 (0 = Disabled)
	29	Not Used		
	30	Communication Failure	0	0 to 15 (0 = Disabled)
	31	Keypad Trouble	0	
	32	Sensor Low Battery	0	
	33	Sensor Superv/Trouble	0	
	34	Force Close	12	0 to 15 (0 = Disabled)
	35	Supervisory Restore	0	

71 1-64 Default Report Code Override Report Code For Specific Sensor

Report Enable for SIA or Contact ID Reporting

72	1	Opening	0	0 = No Report
	2	Closing	0	1 = Report
	3	Force Arm	0	
	4	Automatic Test	0	
	5	Manual Test	1	1 = Report
	6	AC Failure	1	
	7	AC Restore	0	
	8	Control Panel Low Battery	1	
	9	Control Panel Battery Restore	0	
	10	Sensor/Loop Restore	0	
	11	Sensor/Loop Tamper	1	
	12	Sensor/Loop Supervisory	0	
	13	Sensor Low Battery	0	
	14	Supervisory Trouble	1	

73 1-64 SIA/CID Report Override Format #1 (Overrides Report Codes if needed)

1. Press 73 + + Zone (1 to 64) +

2. Enter 1 or 2-digit Override code then

3. Press * to exit

78 1-64 SIA/CID Report Override Format #2

SIA Over-Ride Codes

- | | |
|-------------------|---------------------|
| 1 = Burg Alarm | 7 = Panic Alarm |
| 2 = Fire Alarm | 8 = Sprinkler Alarm |
| 3 = Gas Alarm | 9 = Tamper Alarm |
| 4 = Holdup/Duress | 10 = Untyped Alarm |
| 5 = Heat Alarm | 11 = Water Alarm |
| 6 = Medical Alarm | 12 = Freeze Alarm |

Linear 21st Sentry CP-90 Program Sheet

User Codes (32 total Codes also called PAC's)

Master Code	Usually User 02	(Any User Code can be set as Master)
Temp Code	User 01	
Secondary Code	User 03 to 31	
Duress Code	Usually User 31	(Any User Code can be set as Duress)
Installer Code	User 32	(Default is 98765)

90	2-32	Personal Access Code Entry	_ _ _	1. Press 90 + [? ? ?] + User (2 to 32) + [? ? ?] 2. Enter up to 4 to 5 digits then  3. Press * to exit
91	2-32	Cancel/Delete a PAC		1. Press 90 + [? ? ?] + User (2 to 31) + [? ? ?] 2. Press  to delete 3. Press * to exit
92	2-32	High Security Level Limit	_ 8 _	Highest Security Level this Code can use 9 = Installer Code (Usually Code 32 only) 8 = Sensor Test 7 = Phone Test 6 = Night Secure (Perim Inst, Motion Byp) 5 = Night Arm 4 = Away Arm 3 = Home Arm 2 = Chime Mode 1 = Guard/Cancel (Local Alarm only) 0 = Disarm/Cancel
		Installer Code = 8 Master/Secondary Codes = 7 Duress = 0		
93	2-32	Low Security Level Limit	_ 0 _	Lowest Security Level this Code can use 9 = Installer Code (Usually Code 32 only) 8 = Sensor Test 7 = Phone Test 6 = Night Secure (Perim Inst, Motion Byp) 5 = Night Arm 4 = Away Arm 3 = Home Arm 2 = Chime Mode 1 = Guard/Cancel (Local Alarm only) 0 = Disarm/Cancel
		All Codes set to 0		
94	2-32	Duress PAC	_ 0 _	0 = Normal Code 1 = Duress Code
95	2-32	Master PAC Code	_ 0 _	0 = Normal Code 1 = Master Code
96	2-32	Arm Only PAC	_ 0 _	0 = Normal Security Level Control 1 = Arms to Level 4 Only (Overrides location 92)
97	2-32	No Bypass PAC	_ 0 _	0 = Full Bypass Allowed 1 = No Bypass
98	2-32	Access Output PAC	_ 0 _	0 = No Access Control Output 1 = Access Control Output Activates
99	2-32	Access Output Only	_ 0 _	0 = Normal Security Level Control 1 = Activate Access Output Only
100	2-32	Locked PAC Code	_ 0 _	0 = User Can Change Own Code 1 = User Cannot Change Own Codes
101	2-32	PAC Programming Enable (set at 1 if Master PAC)	_ 0 _	0 = This Code Cannot Set other Codes 1 = Code Program Mode Allowed

Linear 21st Sentry CP-90 Program Sheet

System Times

120	1	Entry Delay Time 1	30	1-250 Seconds
	2	Entry Delay Time 2	45	1-250 Seconds
	3	Exit Delay Time	45	1-250 Seconds
	4	Burglary Output Delay	5	1-250 Seconds
	5	Burglary Output Cutoff	5	0-250 Minutes (0 = Infinite)
	6	Fire Output Cutoff	5	0-250 Minutes (0 = Infinite)
	7	Police Alarm Cutoff	5	0-250 Minutes (0 = Infinite)
	8	Emergency Output Cutoff	5	0-250 Minutes (0 = Infinite)
	9	Access Output On-Time	5	0-250 Minutes (0 = Toggles On/Off)
	10	Automation #1 On-Time	5	0-250 Minutes (0 = Toggles On/Off)
	11	Automation #2 On-Time	5	0-250 Minutes (0 = Toggles On/Off)

System Sounds

121	1	Pulsing Burg Output	0	0 = Steady 1 = Pulsed
	2	Pulsing Fire Output	0	0 = Steady 1 = Pulsed
	3	Multiple Burg Shutdown	0	0 = Multiple Outputs Per Arm/Disarm 1 = Only One Audible Output Per Arm
	4	Day Alert Latch	0	0 = Trouble Light Clears when No Trouble 1 = Trouble Light Latch, Clear w/Status "97"
	5	Bell Test on Arming	0	0 = No Bell Test 1 = Bell Test if Armed to Level 4 or Higher
	6	Keypad Burglary for Lock-Ins	5	0 = Normal 1 = Any Key Starts Entry Delay in Level 4

7	Entry Delay Beeps	1	0 = Beeps Off 1 = Beeps On
8	Exit Delay Beeps	1	0 = Beeps Off 1 = Beeps On

9	Silent Police Alarms	1	0 = Audible 1 = Silent	
10	Silent Emergency Alarms	0	0 = Audible 1 = Silent	
11	Silent Burg Alarms	0	0 = Audible 1 = Silent	
12	Disable Quick Arming	0	0 = Quick Arming Allowed 1 = Quick Arming Not Allowed	
13	Automatic Bypass on Restoral	0	0 = Bypass Clear on Restoral 1 = Bypass Remain on Restoral	
14	Auto Bypass Arming	0	0 = Auto Bypass then Arm 1 = No Arm until Quick Bypass	
15	Receiver Desense/Sensitivity	0	0 = Normal Sensitivity 1 = Reduced Sensitivity (-6dB)	
121	16	Alarm Memory Latch for Sensors	0	0 = No Alarm Memory Latch 1 = Alarm Memory & LED Latches
17	Auto Alarm Memory Display	0	0 = Manual Alarm Mem Disp w/Status "96" 1 = Auto Alarm Mem Disp after Alarm	
18	24-Hr System Status Display	1	0 = Status Only w/Manually Checking 1 = Sensor Status on at All Times	
19	KD-90 Communicator Status Display	0	0 = No Communicator Status Display 1 = Communicator Status Displays	
20	Master Reset Disable (This will lockout system)	0	0 = Master Reset Switch Enabled 1 = Master Reset Switch Disabled	
21	Event Log Limiter	0	0 = No Limits on Adding to Event Log 1 = 200 Events will be Logged until Cleared	
22	Audible Sensor Trouble	0	0 = Sensor Trouble Only displays on Keypad 1 = Sensor Trouble on KP, Chime every Minute	
23	Quick Bypass Disable	0	0 = Quick Bypass Allowed 1 = No Quick Bypass	

Linear 21st Sentry CP-90 Program Sheet

Event Logging


122	1	Sensor & Test Logging	0	0 = Log only Alarms, 1 = Log All
	2	Sensor Restoral	1	0 = No Logging, 1 = Log Events
	3	Normal Opening & Closing	1	0 = No Logging, 1 = Log Events
	4	Forced Closing	1	0 = No Logging, 1 = Log Events
	5	Opening After an Alarm	1	0 = No Logging, 1 = Log Events
	6	Sensor & Accessory Supervision	1	0 = No Logging, 1 = Log Events
	7	Panel Reset, Test and Superv	1	0 = No Logging, 1 = Log Events
	8	Communicator	1	0 = No Logging, 1 = Log Events
	9	Panel Programming	1	0 = No Logging, 1 = Log Events
	10	Fire, Burg, Emergency Outputs	1	0 = No Logging, 1 = Log Events

LCD Keypad Alpha Zone Descriptors


EMERGENCY Key moves cursor to beginning # moves forward 255 erases anything after cursor

0 = 0	51 = O	102 = Downstairs	153 = Library	204 = Room
1 = 1	52 = P	103 = Drawer	154 = Lift	205 = Safe
2 = 2	53 = Q	104 = Dressing	155 = Light	206 = Screen
3 = 3	54 = R	105 = Driveway	156 = Liquor	207 = Second
4 = 4	55 = S	106 = East	157 = Living	208 = Security
5 = 5	56 = T	107 = Electric	158 = Loading	209 = Sensor
6 = 6	57 = U	108 = Elevator	159 = Lobby	210 = Shipping
7 = 7	58 = V	109 = Emergency	160 = Locker	211 = Shock
8 = 8	59 = W	110 = Employee	161 = Loft	212 = Shop
9 = 9	60 = X	111 = Entrance	162 = Lower	213 = Shutter
10 = Blank Space	61 = X	112 = Exercise	163 = Main	214 = Side
11 = a	62 = Z	113 = Exit	164 = Maintenance	215 = Silent
12 = b	63 = !	114 = Exterior	165 = Master	216 = Silver
13 = c	64 = #	115 = Factory	166 = Mat	217 = Skylight
14 = d	65 = &	116 = Family	167 = Medical	218 = Sliding
15 = e	66 = '	117 = Fire	168 = Microwave	219 = Smoke
16 = f	67 = (118 = First	169 = Middle	220 = South
17 = g	68 =)	119 = Floor	170 = Monitor	221 = Spa
18 = h	69 = *	120 = Flow	171 = Motion	222 = Sprinkler
19 = i	70 = +	121 = Fluid	172 = Mud	223 = Stairs
20 = j	71 = ,	122 = Foil	173 = North	224 = Station
21 = k	72 = -	123 = Foyer	174 = Nursery	225 = Steam
22 = l	73 = .	124 = Freezer	175 = Office	226 = Stereo
23 = m	74 = /	125 = Front	176 = On/Off	227 = Stock
24 = n	75 = =	126 = Furnace	177 = Outside	228 = Storage
25 = o	76 = Access	127 = Game	178 = Overhead	229 = Study
26 = p	77 = Alarm	128 = Garage	179 = Panic	230 = Sump
27 = q	78 = Area	129 = Gas	180 = Parking	231 = System
28 = r	79 = Arm	130 = Gate	181 = Passive	232 = Tamper
29 = s	80 = Attic	131 = Glass	182 = Patio	233 = Temperature
30 = t	81 = Audio	132 = Guest	183 = Perimeter	234 = Third
31 = u	82 = Auxiliary	133 = Gun	184 = Photo	235 = Tool
32 = v	83 = Back	134 = Hallway	185 = PIR	236 = Transmitter
33 = w	84 = Basement	135 = Heat	186 = Play	237 = Remote
34 = x	85 = Bathroom	136 = Hobby	187 = Plant	238 = Ultrasonic
35 = y	86 = Beam	137 = Hold	188 = Police	239 = Upper
36 = z	87 = Bedroom	138 = Hold-up	189 = Pool	240 = Upstairs
37 = A	88 = Breakfast	139 = House	190 = Power	241 = Utility
38 = B	89 = Button	140 = Ice	191 = Proximity	242 = Valve
39 = C	90 = Cabinet	141 = Infrared	192 = Pump	243 = Vault
40 = D	91 = Carport	142 = Inside	193 = Quarters	244 = Vibration
41 = E	92 = Ceiling	143 = Interior	194 = Ramp	245 = Video
42 = F	93 = Chime	144 = Intrusion	195 = Rear	246 = Violation
43 = G	94 = Closet	145 = Janitor	196 = Receiving	247 = Wall
44 = H	95 = Computer	146 = Key	197 = Recreation	248 = Warehouse
45 = I	96 = Control	147 = Keypad	198 = Relay	249 = Water
46 = J	97 = Den	148 = Keyswitch	199 = Remote	250 = West
47 = K	98 = Detector	149 = Kitchen	200 = Restroom	251 = Window
48 = L	99 = Dining	150 = Laundry	201 = RF	252 = Yard
49 = M	100 = Dock	151 = Left	202 = Right	253 = Zone
50 = N	101 = Door	152 = Level	203 = Roof	254 = NULL (Nothing)
				255 = Erase Entire Line

Linear 21st Sentry CP-90 Program Sheet



Linear 21st Sentry CP-90 Program Sheet



Mark Leuck 07/03/01

Monitronics 21st Sentry CP-90 Quick Reference Guide

Monitoring and Service call 1-800-447-9239

Arm Away	4 then User Code
Arm Stay	3 then User Code
Arm Instant	6 then User Code
Disarming	0 then User Code
Arm Instant	6 then User Code
Status	Press [? ? ?] to show Arming Level Press and hold [? ? ?] for 1 second to view status of Zones
Zone Bypassing	1. Arm system in Stay or Away mode 2. Press [] then enter Zone to bypass (01 to 64) or 1. Arm system with Zone or Zones open 2. Press [] for 2 seconds, all open Zones will be bypassed
User Codes	1. Press # + Master Code 2. Hold # until keypad beeps 3. Enter User to change or add (03 to 32) then # 4. Enter new User Code (4 to 5 digits) then # 5. Enter 6-digit User Level 1 st digit = Highest level User can Arm system (see list at right) 2 nd digit = Lowest level User can Disarm system (see list at right) 3 rd digit = 0 for Normal User Code, 1 for Duress Code, 2 for Master Code, 3 = Arm Only Code 4 th digit = 0 to allow Zone Bypassing, 1 to not allow Zone Bypassing 5 th digit = 0 for No Access Control Output, 1 allows Access Control Output 6 th digit = 0 if User can change own User Code, 1 if User cannot change own User Code Press # to save and exit Example: to program user 03 as a standard User Code of 5555 enter # + Master Code + # + Hold # until keypad beeps + 03 + # + 5555 + # + 8 0 0 0 1 + #
Door Chimes	Press 2 then enter User Code
Fire/Smoke Detector Reset	Press [? ? ?] then 99
Clear Alarm Display	Press [? ? ?] then 97
System Troubles	If Trouble Light is ON press [? ? ?] for 1 second to view 2-digit Trouble 73 = Communication Failure 74 = Panel Low Battery 75 = Auxiliary Power Fuse Failure 76 = Fire Power Fuse Failure 77 = Wireless Receiver Failure 78 = System Low Battery 79 = Panel Box Tamper Trouble 80 = AC Power Failure 86 = Internal System Trouble 87 = Keypad exists but not installed in system 88 = EEPROM Write Failure (Internal System Trouble) 89 = Watchdog Trouble (Internal System Trouble)

- User Code Levels**
- 0 = Disarm
 - 1 = Guard Mode
 - 2 = Chime Mode
 - 3 = Home Arm
 - 4 = Away Arm
 - 5 = Night Arm
 - 6 = Secure Night Arm
 - 7 = Phone Test
 - 8 = Sensor Test